














# Cisco 7965

## Phone layout



1	Programmable Buttons 	Depending on configuration, programmable buttons provide access to: <ul style="list-style-type: none"> <li>• Phone lines (line buttons) and intercom lines</li> <li>• Speed-dial numbers (speed-dial buttons, including the BLF speed-dial feature)</li> <li>• Web-based services (for example, a Personal Address Book button)</li> <li>• Call features (for example, a Privacy, Hold, or Transfer button)</li> </ul>
2	Footstand Button	Enables you to adjust the angle of the phone base.
3	Display Button 	Awakens the phone from sleep mode.
4	Messages Button 	Auto-dials your voicemail service.
5	Directories Button 	Opens/closes Directories menu. Use it to access call logs and directories.
6	Help Button 	Activates the Help Menu.
7	Settings Button 	Opens/closes the Settings Menu. Use it to change phone screen and ring settings.
8	Services Button 	Opens/closes the Services Menu.

9	Volume Button 	Controls the handset, headset and speakerphone volume (off- hook), and the ringer volume (on-hook).
10	Speaker Button 	Toggles the speakerphone on or off. When the speakerphone is on, the button is lit.
11	Mute Button 	Toggles the microphone on or off. When the microphone is on, the button is lit.
12	Headset Button 	Toggles the headset on or off. When the headset is on, the button is lit.
13	4-Way Navigation Pad and Select Button (centre) 	Enables you to scroll through menus and highlight items. Use the select button to select an item that is highlighted on the screen.  Navigation button—Scroll up and down to see menus and highlight items, and right and left across multi-column displays.  Select button—Scroll to highlight a line using the Navigation button and then press  to open a menu, play a ringer item, or access other features, as described on the screen.
14	Keypad	Enables you to dial phone numbers, enter letters, and choose menu items.
15	Softkey Buttons	Each activates a softkey option (displayed on your phone screen).
16	Handset light strip	Indicates an incoming call (flashing red) or new voice message
17	Phone Screen	Shows information about your phone such as directory number, active call and line status, softkey options, speed dials, placed calls, and phone menu listings.