









Cisco 7945

Phone layout



1	Voicemail Message Waiting Indicators	Indicates an incoming call or new voice message.
2	Phone Buttons	Depending on configuration, phone buttons provide access to: Phone lines and intercom lines (line buttons) Speed-dial numbers (including the busy lamp speed-dial feature) Phone features (for example, a Privacy)
3	Softkeys	Each activates a softkey option (displayed on your phone screen).
4	Footstand Button	Allows you to adjust the angle of the phone base.
5	Display Button	Awakens the phone screen from sleep mode.
6	 Messages Button	Auto-dials your voice message service (varies by service).
	 Directories Button	Opens/closes the Directories menu. Use it to access call logs and directories.
	 Services Button	Opens/closes the Services menu.

	 Settings Button	Opens/closes the Settings menu. Use it to change phone screen and ring settings.
7	 Volume Button	Controls the handset, headset, and speakerphone volume (off-hook) and the ringer volume (on-hook).
8	 Headset Button	Toggles the headset on or off. When the headset is on, the button is lit.
	 Mute Button	Toggles the microphone on or off. When the microphone is muted, the button is lit.
	 Speaker Button	Toggles the speakerphone on or off. When the speakerphone is on, the button is lit.